

Installation Instructions  
For the  
Fender Extenders  
Part # 1013, 1023, 1923

1. Drill 5/32" diameter holes through the premarked holes in the fender. (The holes are premarked with small indentions.) Note: On the rear fender extender, only one of the two premarked holes at each end of the fender needs to be drilled. On the right and left rear extenders, drill the upper hole on the front end of the fender and the lower hole on the rear end of the fender.
2. After drilling the correct holes in the fenders, position the fender extender in place on the vehicle. While holding the fender firmly in position, drill a 1/8" hole through one of the holes in the fender. It is important that you use the correct size drill bit. Then, install one of the self-tapping metal screws with a washer as provided.
3. Repeat step 3 until all screws have been installed.

For extended outdoor use we strongly suggest a UV protector-Apply a durable automotive clear coat finish or regularly apply an automotive plastic or vinyl cleaner-protectant.