

# D-18 PTO Adapter kit for overdrive

This is a kit that allows you to adapt a Power Take-off unit (such as a Ramsey or Koenig) that fits any standard D-18 transference. This does not affect the function of your overdrive. This kit will fit, but is not limited to, the original Warn overdrive as well as the Saturn overdrive,

The kit includes:

- PTO adapter aluminum housing
- special sprocket gear
- special washer
- gaskets (2)
- pipe plug for oil drain hole
- cotter pin

The installation is simple. Unbolt rear cap of overdrive, take nut and spacer off overdrive spline shaft, torque special sprocket gear and nut on shaft to about 24 ft.lb. Secure with cotter pin, bolt on adapter housing. The installation of your PTO is now basically the same as it would be on a stock D-18 before it had the overdrive.

If you have a Husky overdrive you will need to specify at the time of the order, as a special spacer is required, the rest of the parts are the same.